

Sensors (Pebble3-4/Dualys2-3/Securion)

How to adjust them?

One command can be sent to adjust all the sensors at once:

- Make sure a color ribbon and cards are inside the printer.
- In the **Driver properties/Tools/Dialog with printer**, send the **Sa** command:
- The “warning-LED” from the control panel will flash.
- Open the cover. The “warning-LED” will stop. When it’s on again, close the cover.
- The “card-LED” will flash. Take out the feeder. The “card-LED” will stop. When it’s on again, put it back.
- The card will be fed, ejected then the sensors will be adjusted.

→ If this procedure has been followed too slowly, a “timeout elapsed” message may be displayed.

